



FIRST GENERATION – (WITH BLACK REMOTE CONTROL)

REPROGRAMMING THE GLOBECAST RECEIVER FOR THE AMC-4 SATELLITE

1. Press **[MENU]** button on the remote control
2. Press right button on remote to go to **[CHANNEL]** menu
3. Press up or down button on remote to go **[Factory Default]**
4. Press OK button on remote control
5. Enter password **[0000]** with remote control
6. Press left arrow on remote control to choose **[YES]** box
7. Press OK button on remote control
8. Select **[Program New Channels]** and press OK button on remote control
9. Enter password **[0000]** with remote control
10. Press OK button on remote control
11. Select **[New SAT]** and press OK button on remote control (keypad appears)
12. Go to "A" and press OK on remote control
13. Go to "M" and press OK on remote control
14. Go to "C" and press OK on remote control
15. Go to "4" and press OK on remote control
16. Press OK button on remote control
17. Go to **[LNB Type]** and choose option **[10750]** with left or right arrow button
18. Go to **[LNB Power]** and choose option **[On]** with left or right arrow button
19. Go to **[Command]** and choose [Save] then press OK button on remote control
20. Select your satellite (**AMC4**) and press OK on remote control
21. Select **[Edit Transponder Parameters]** and press OK button
22. On [TP.No] menu choose [1]
23. Press down arrow to **[Frequency]**
24. With number buttons on remote control enter: **[12120]** and press OK button
25. Press down arrow to **[Symbol Rate]**
26. With number buttons on remote control enter: **[30000]** and press OK button
27. Press down arrow to [Polarity] and set it to **[Vertical]**
28. Press down arrow to [Command] and choose **[Search]** then press OK button
29. Finished Loading should look like this: Transponder must be **[1/1]**
Status must say **[LOCKED]** and Yellow bar must be **[100%]**
30. Press button **[EXIT]** on remote control and on TV screen you should see TV program



SECOND GENERATION – (WITH SILVER REMOTE CONTROL)

REPROGRAMMING THE GLOBECAST RECEIVER FOR THE AMC-4 SATELLITE

1. Turn on the remote control press MENU. The **[Main Menu]** will appear on the screen.
2. Press the up or down arrow on the remote to go to **[Setup]**
3. Press the right arrow to go to the Setup list on the right
4. Go to seven (7) **[Factory Default]** with the down arrow
5. Press OK on the remote
6. Enter password 0000 (four (4) zeros)
7. With the UP arrow highlight **[OK]**
8. Press OK on the remote
9. After the reset a Message Box will appear with “No Program found”
10. Press OK on the remote
11. After the Main Menu appears go down to **[Setup]**
12. With the right arrow go to the list on the right
13. Go to (2) **[Antenna Setup]**
14. Press OK on the remote
15. Go down to **[GlobeCast]**
16. Press the right arrow until **[Newsat01]** appears
17. Press EXIT on the remote
18. Press the right arrow on the remote. (OK appears)
19. Press OK on the remote. The **[Main Menu]** will appear on the screen
20. Go down to (3) **[Channel Search]**
21. Press OK on the remote
22. Go down to **[TP1]**
23. Press the red button on the remote (2 x **[New]** appears)
24. Go down to the first **[New]**
25. With numerical keys input **[12120]**
26. Go down to the second **[New]**
27. With the numerical keys input **30000**
28. Go up to **[Newsat01]**
29. Press the yellow button on the remote. (The keypad appears)
30. Go down to “**A**” and press OK on the remote
31. Go to “**M**” and press OK on the remote
32. Go to “**C**” and press OK on the remote
33. Go to “**4**” and press OK on the remote
34. Go all the way down to **[OK]** so it is highlighted
35. Press OK on the remote
36. Go all the way down to **[Search Network]**
37. Press the right arrow on the remote until **[Search TP]** appears
38. Press OK on the remote. (A search is started)
39. Go to **[Exit]** so it is highlighted
40. Press OK on the remote
41. Press EXIT on the remote
42. By pressing OK on the remote a list of available channels will appear.
43. Choose the desired channel and press OK on the remote
44. Press button **[EXIT]** on remote control and on TV screen you should see TV program